

INSTALLATION INSTRUCTIONS

"Recessed Floor Matting"

BEFORE YOU BEGIN:

Unroll product so it can lay flat and relax for minimum 24 hours. The product expands when it is unrolled. If you trim it into the well immediately after unrolling, it will ripple in the well as it expands and you will need to re-trim the mat.

TOOLS REQUIRED:

- Utility Knife
- Tape Measure

PROCEDURES

1. Verify dimensions of the well versus dimensions of the floor mat to make sure the mat is large enough to cover the entire area. Also, make sure any logos or designs are positioned in the mat to your satisfaction before proceeding with the installation.

NOTE: IF ANYTHING ABOUT THE MAT IS INCORRECT OR UNSATISFACTORY, NOTIFY YOUR PRODUCT CONSULTANT IMMEDIATELY. Once cut, you have accepted the product and all its attributes.

2. With YARN SIDE UP, lay the mat over the recessed area. If you HAVE a design/logo in your mat, make sure it is centered in the well. If you do NOT have a design or logo in the mat, lay one corner into the well so two sides are flush.

3. Using the utility knife (**with a sharp blade**) trim the mat into place, cutting on the yarn side, and utilizing the lip of the well as a straight edge to push your knife blade against. Trim the required sides into place.

4. Vacuum the mat and make sure it is lying flat in the well.

IMPORTANT!

**Before starting installation
RECESS MUST BE SWEEPED & SCRUBBED**
in order for the back side of the
floor mat to properly grip the floor.



Ph: 800-468-0860

Fax: 515-295-4874

www.sbemco.com

KNOWN BY OUR PINK & BLUE BACKING