

# Installation Instructions

## Recessed Floor Matting

### BEFORE YOU BEGIN

Unroll product so it can lay flat and relax for a minimum of 4 hours. The product expands when it is unrolled. If you trim it into the well immediately after unrolling, it will ripple in the well as it expands and you will need to re-trim the mat.

### TOOLS REQUIRED

- Utility Knife
- Tape Measure

#### **IMPORTANT!**

***Before starting installation***

**RECESS MUST BE SWEEPED & SCRUBBED**

in order for the back side of the floor mat to properly grip the floor.

### PROCEDURES

1. Verify dimensions of the well versus dimensions of the floor mat to make sure the mat is large enough to cover the entire area. Also, make sure any logos or designs are positioned in the mat to your satisfaction before proceeding with the installation.

**NOTE: IF ANYTHING ABOUT THE MAT IS INCORRECT OR UNSATISFACTORY, NOTIFY YOUR PRODUCT CONSULTANT IMMEDIATELY. Once cut, you have accepted the product and all its attributes.**

2. With **YARN SIDE UP**, lay the mat over the recessed area. If you **HAVE** a design or logo in your mat, make sure it is centered in the well. If you do **NOT** have a design or logo in the mat, lay one corner into the well so two sides are flush.
3. Using a **sharp-bladed utility knife**, trim the mat into place by cutting on the yarn side and utilizing the lip of the well as a straight edge – pushing your knife blade against it. Trim the required sides into place.
4. Vacuum the mat and make sure it is lying flat in the well.

## **NO ADHESIVES**

**ARE TO BE USED ON ANY  
MATTING BY DESIGN PRODUCT UNLESS  
AUTHORIZED BY THE FACTORY.**



**“KNOWN BY OUR BACKING”**

Customer Service Phone: 800-468-0860 x33

[www.MattingByDesign.com](http://www.MattingByDesign.com)